DEAL INDICATOR

Care and Use of Ideal Indicators: The contact can be moved into any position from one side of the indicator to the other according to the requirements of the work to be tested. This is done by simply pushing it into the desired position. A little more pressure is required to change the position of the contact than is required to move the indicating finger across the scale. Keep free from dirt, dust and oil as much as possible.

When inclined to stick, hold contact between thumb and finger and move it back and forth quickly, causing the finger to move from one extreme end of the scale to the other in rapid succession; repeat this operation with the contact in various succession; repeat this operation with the contact in various positions; this will tend to remove any particle of dirt that may have become lodged inside of the indicator.

Repairs: Send ONLY the part that needs repairing direct to

factory. A card will be mailed to you stating cost. Upon receipt of money immediate attention will be given.

\$.65

1.10

.35

.50

.15

Extra Parts:

Contact complete with lever . .

Special Smaller Contacts of 1/16, 3/64 or 1/32 each.

Indicating finger. Twin indicating finger for Double Scale Ideal Indicator

Three cover plate screws..

Tool-post Holder for Single or Double Scale Indicator .35 IDEAL INDICATOR Actual Size

wavelesting or indicating is The advantage of an INDICATOR with accurate readings from front or rear is obvious, especially when indicating holes, or where the

INDICATOR is fastened to a revolving spindle. **Single Scale**

IDEAL. INDICATOR

Double Scale Indicator with Holder. 6.00

Equipped with smaller Contact, either 1/16, 3/64 or 6.50 Single Scale Indicator with Holder. Equipped with smaller Contact, either 1/16, 3/64 or

5.00 Specify either Single or Double Scale when ordering.

IDEAL TOOL COMPANY

Office and Factory, 407 River Street, Rochester 12, New York

HOLDING CLAMP FOR IDEAL INDICATOR (Illustrated below) Price of Clamp only \$2.50



The universal ball joint and the adjustable brackets give this clamp a great range of adaptability as it can be fastened on to any convenient place where accurate testing or indicating is to be done.

IDEAL CENTER TESTER



This tool is used in connection with the IDEAL TEST INDICATOR. It will true up a prick punch mark quicker and more accurately than a Wiggler, either on work revolving or stationary.

For further particulars of these tools ask your dealer, or write to

Ideal Tool Co., 407 River Street, Rochester 12, N. Y.